

ENGINE SECTION 1

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FUEL INJECTION (FUEL SYSTEMS)	FU(H4SO 2.0)
EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)	EC(H4SO 2.0)
INTAKE (INDUCTION)	IN(H4SO 2.0)
MECHANICAL	ME(H4SO 2.0)
EXHAUST	EX(H4SO 2.0)
COOLING	CO(H4SO 2.0)
LUBRICATION	LU(H4SO 2.0)
SPEED CONTROL SYSTEMS	SP(H4SO 2.0)
IGNITION	IG(H4SO 2.0)
STARTING/CHARGING SYSTEMS	SC(H4SO 2.0)
ENGINE (DIAGNOSTICS)	EN(H4SO 2.0) (diag)
FUEL INJECTION (FUEL SYSTEMS)	FU(H4SO 2.5)
EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)	EC(H4SO 2.5)
INTAKE (INDUCTION)	IN(H4SO 2.5)
MECHANICAL	ME(H4SO 2.5)
EXHAUST	EX(H4SO 2.5)
COOLING	CO(H4SO 2.5)

ENGINE SECTION 1

LUBRICATION

LU(H4SO 2.5)

SPEED CONTROL SYSTEMS

SP(H4SO 2.5)

IGNITION

IG(H4SO 2.5)

STARTING/CHARGING SYSTEMS

SC(H4SO 2.5)

ENGINE (DIAGNOSTICS)

EN(H4SO 2.5)
(diag)

FUEL INJECTION (FUEL SYSTEMS)

FU(H4SO 2.0)

	Page
1. General Description	2
2. Throttle Body	10
3. Intake Manifold	11
4. Engine Coolant Temperature Sensor	20
5. Crankshaft Position Sensor	21
6. Camshaft Position Sensor	22
7. Knock Sensor	23
8. Throttle Position Sensor	25
9. Manifold Absolute Pressure Sensor	26
10. Intake Air Temperature Sensor	27
11. EGR Valve	28
12. Fuel Injector	29
13. Front Oxygen (A/F) Sensor	32
14. Rear Oxygen Sensor	33
15. Engine Control Module (ECM)	34
16. Main Relay	35
17. Fuel Pump Relay	36
18. Electronic Throttle Control Relay	37
19. Fuel	38
20. Fuel Tank	39
21. Fuel Filler Pipe	45
22. Fuel Pump	47
23. Fuel Level Sensor	49
24. Fuel Sub Level Sensor	50
25. Fuel Filter	51
26. Fuel Damper Valve	52
27. Fuel Delivery, Return and Evaporation Lines	53
28. Fuel System Trouble in General	56

General Description

FUEL INJECTION (FUEL SYSTEMS)


1. General Description

A: SPECIFICATION

Fuel tank	Capacity	64 ℓ (16.9 US gal, 14.1 Imp gal)
	Location	Under rear seat
Fuel pump	Type	Impeller
	Shutoff discharge pressure	441 — 686 kPa (4.50 — 7.00 kg/cm ² , 64.0 — 99.5 psi)
	Discharge	75 ℓ (19.8 US gal, 16.5 Imp gal)/h or more [12 V at 300 kPa (3.06 kg/cm ² , 43.5 psi)]
Fuel filter		In-tank type

B: COMPONENT

1. INTAKE MANIFOLD



FU-02056

General Description

FUEL INJECTION (FUEL SYSTEMS)

- | | | |
|----------------------------------|-----------------------------------|----------------|
| (1) Intake manifold | (10) O-ring | (19) PCV valve |
| (2) Gasket | (11) Purge control solenoid valve | |
| (3) Guide pin | (12) Plug cord holder | |
| (4) EGR valve (EC, EK, K4 model) | (13) Nipple (LHD model) | |
| (5) Fuel pipe protector RH | (14) Nipple (RHD model) | |
| (6) Fuel pipe protector LH | (15) Fuel pipe ASSY | |
| (7) Fuel injector pipe | (16) Fuel hose | |
| (8) Fuel injector | (17) Clip | |
| (9) O-ring | (18) Clamp | |

Tightening torque: N·m (kgf-m, ft-lb)

T1: 1.5 (0.15, 1.1)

T2: 6.4 (0.65, 4.7)


T3: 17 (1.7, 12.5)

T4: 19 (1.9, 13.7)

T5: 25 (2.5, 18.1)

T6: 23 (2.3, 17.0)

2. AIR INTAKE SYSTEM



FU-02057


- | | |
|---------------------------------------|------------|
| (1) Gasket | (4) O-ring |
| (2) Throttle body | |
| (3) Manifold absolute pressure sensor | |

Tightening torque: N·m (kgf-m, ft-lb)

T1: 2.0 (0.20, 1.5)

T2: 8 (0.8, 5.8)

3. CRANKSHAFT POSITION, CAMSHAFT POSITION AND KNOCK SENSORS



- (1) Crankshaft position sensor
- (2) Knock sensor
- (3) Camshaft position sensor

- (4) Camshaft position sensor support

Tightening torque: N·m (kgf·m, ft·lb)


T1: 6.4 (0.65, 4.7)

T2: 24 (2.4, 17.4)

General Description

FUEL INJECTION (FUEL SYSTEMS)

4. FUEL TANK



FU-01080

General Description

FUEL INJECTION (FUEL SYSTEMS)

(1) Fuel tank	(12) Fuel sub level sensor upper plate	(22) Retainer
(2) Fuel tank band RH	(13) Fuel sub level sensor gasket	(23) Heat shield cover
(3) Fuel tank band LH	(14) Fuel filler hose	(24) Fuel tank protector RH (Front)
(4) Delivery tube	(15) Clamp	(25) Fuel tank protector LH (Front)
(5) Return tube	(16) Vent hose	
(6) Jet pump tube	(17) Clip	
(7) Fuel pump assembly	(18) Fuel tank protector RH (Rear)	
(8) Fuel pump upper plate	(19) Fuel tank protector LH (Rear)	
(9) Fuel pump gasket	(20) Stopper RH	
(10) Fuel level sensor	(21) Stopper LH	
(11) Fuel sub level sensor		

Tightening torque: N·m (kgf-m, ft-lb)**T1: 4.4 (0.45, 3.3)****T2: 9.0 (0.92, 6.6)****T3: 17.5 (1.78, 12.9)****T4: 33 (3.4, 25)**

General Description

FUEL INJECTION (FUEL SYSTEMS)

- | | | |
|---------------------------------------|-------------------------------|----------------------------|
| (1) Clip | (14) Two-way valve hose A | (27) Filler cap |
| (2) Fuel return hose | (15) Purge hose A | (28) Tether |
| (3) Evaporation hose A | (16) Purge hose B | (29) Clip |
| (4) Fuel delivery hose A | (17) Two-way valve hose B | (30) Fuel hose |
| (5) Fuel delivery hose B | (18) Canister drain hose B | (31) Purge hose C |
| (6) Fuel damper | (19) Two-way valve drain hose | (32) Connector |
| (7) Fuel damper holder | (20) Two-way valve | (33) Purge pipe |
| (8) Fuel damper bracket | (21) Two-way valve hose C | (34) Two-way valve bracket |
| (9) Fuel pipe ASSY | (22) Connector | |
| (10) Clamp | (23) Evaporation hose holder | |
| (11) Canister | (24) Fuel filler pipe ASSY | |
| (12) Canister protector (Sedan model) | (25) Filler pipe packing | |
| (13) Canister drain hose A | (26) Filler ring | |

Tightening torque: N·m (kgf-m, ft-lb)

T1: 4.4 (0.45, 3.2)

T2: 7.5 (0.76, 5.53)


T3: 8.3 (0.85, 6.1)

C: CAUTION

- Wear work clothing, including a cap, protective goggles and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.

- Be careful not to burn yourself, because each part on the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the ground cable from battery.
- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.

D: PREPARATION TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST24082AA230</p>	24082AA230	CARTRIDGE	Troubleshooting for electrical system.
 <p>ST22771AA030</p>	22771AA030	SUBARU SELECT MONITOR KIT	Troubleshooting for electrical system. <ul style="list-style-type: none"> • English: 22771AA030 (Without printer) • German: 22771AA070 (Without printer) • French: 22771AA080 (Without printer) • Spanish: 22771AA090 (Without printer)


Throttle Body

FUEL INJECTION (FUEL SYSTEMS)

2. Throttle Body


A: REMOVAL

1) Disconnect the ground cable from battery.



2) Remove the air intake chamber. <Ref. to IN(H4SO 2.0)-8, REMOVAL, Air Intake Chamber.>

3) Disconnect the connectors from the throttle position sensor and manifold absolute pressure sensor.




(A) Throttle position sensor

(B) Manifold absolute pressure sensor

4) Disconnect the engine coolant hoses from throttle body.

5) Remove the bolts which secure throttle body to intake manifold.



B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Use a new gasket.


Tightening torque:

8 N·m (0.8 kgf·m, 5.8 ft·lb)


3. Intake Manifold

A: REMOVAL


- 1) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 2) Open the fuel filler flap lid, and remove the fuel filler cap.
- 3) Disconnect the ground cable from battery.




- 4) Remove the air cleaner case and air intake chamber. <Ref. to IN(H4SO 2.0)-6, REMOVAL, Air Cleaner Case.> <Ref. to IN(H4SO 2.0)-8, REMOVAL, Air Intake Chamber.>
- 5) Disconnect the spark plug cords from spark plugs.
- 6) Disconnect the engine coolant hoses from throttle body.




- 7) Disconnect the PCV hose from intake manifold.
- 8) Disconnect the brake booster hose.




- 9) Disconnect the engine harness connectors from bulkhead harness connectors.




- 10) Disconnect the connectors from engine coolant temperature sensor.



- 11) Disconnect the knock sensor connector.



- 12) Disconnect the connector from crankshaft position sensor.




- 13) Disconnect the connector from power steering pump switch (A).


Intake Manifold

FUEL INJECTION (FUEL SYSTEMS)


14) Disconnect the connector from oil pressure switch (B).



15) Disconnect the connector from camshaft position sensor.



16) Remove the EGR pipe from intake manifold. (EC, EK, K4 model)




17) Disconnect the fuel hoses from fuel pipes.

WARNING:


- Be careful not to spill fuel.

- Catch the fuel from hoses using a container or cloth.



- (A) Fuel delivery hose
- (B) Return hose
- (C) Evaporation hose

18) Remove the bolts which secure intake manifold to cylinder head.



19) Remove the intake manifold.

B: INSTALLATION


1) Install the intake manifold onto cylinder heads.

NOTE:

Use a new gasket.

Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)



2) Connect the fuel hoses.


Intake Manifold

FUEL INJECTION (FUEL SYSTEMS)

NOTE:

If fuel hoses or clamps are damaged, replace them with new ones.


Tightening torque (Hose clamp screw):
1.25 N·m (0.13 kgf-m, 0.94 ft-lb)




- (A) Fuel delivery hose
- (B) Return hose
- (C) Evaporation hose

3) Install the EGR pipe to intake manifold. (EC, EK, K4 model)

Tightening torque:
34 N·m (3.4 kgf-m, 24.6 ft-lb)




4) Connect the connector to camshaft position sensor.




5) Connect the connector to power steering pump switch (A).


6) Connect the connector to oil pressure switch (B).




7) Connect the connector to crankshaft position sensor.



8) Connect the knock sensor connector.



9) Connect the connectors to engine coolant temperature sensor.




10) Connect the PCV hose to intake manifold.


Intake Manifold

FUEL INJECTION (FUEL SYSTEMS)


11) Connect the brake booster hose.




12) Connect the engine harness connectors to bulkhead harness connectors.



13) Connect the engine coolant hoses to throttle body.




- 14) Connect the spark plug cords to spark plugs.
- 15) Install the air cleaner case and air intake chamber. <Ref. to IN(H4SO 2.0)-7, INSTALLATION, Air Cleaner Case.> <Ref. to IN(H4SO 2.0)-8, INSTALLATION, Air Intake Chamber.>
- 16) Install the fuse of fuel pump to main fuse box.
- 17) Connect the battery ground cable to battery.



C: DISASSEMBLY

1) Disconnect the engine ground terminal from intake manifold.




2) Remove the ignition coil & ignitor ASSY. <Ref. to IG(H4SO 2.0)-8, REMOVAL, Ignition Coil & Ignitor ASSY.>


3) Remove the throttle body. <Ref. to FU(H4SO 2.0)-10, REMOVAL, Throttle Body.>

4) Remove the EGR valve. (EC, EK, K4 model) <Ref. to FU(H4SO 2.0)-28, REMOVAL, EGR Valve.>


5) Disconnect the pressure regulator vacuum hose from intake manifold.




6) Remove the fuel pipe protector LH.





7) Remove the fuel pipe protector RH.



• RH side







8) Disconnect the connectors from fuel injector.



9) Remove the purge control solenoid valve. <Ref. to EC(H4SO 2.0)-7, REMOVAL, Purge Control Solenoid Valve.>

10) Remove the harness band (A) and bolts (B), (C) which secure engine harness to intake manifold.

• LH side



13) Remove the fuel injector.


11) Remove the engine harness from intake manifold.

12) Remove the bolts which install injector pipe on the intake manifold as shown in the figure.

Intake Manifold


FUEL INJECTION (FUEL SYSTEMS)

- (1) Remove the clip which secures fuel injector from injector pipe.




- (2) Remove the fuel injector with lifting up the fuel injector pipe.

- 14) Loosen the clamp which holds fuel injector pipe LH to fuel hose, and then disconnect the pipe from fuel hose.




- 15) Loosen the clamp which holds fuel injector pipe RH to fuel hose, and then disconnect the pipe from fuel hose.



- 16) Remove the fuel injector pipe.

- 17) Remove the bolt which installs fuel pipes on intake manifold.



- 18) Remove the fuel pipe assembly and pressure regulator, from intake manifold.

D: ASSEMBLY

- 1) Install the fuel pipe assembly and pressure regulator to intake manifold.

NOTE:

- Use a new gasket.
- When assembling the nipple, apply liquid gasket.


Liquid gasket:

THREE BOND 1105 (Part No. 004403010)


- 2) Tighten the bolt which installs fuel pipes on intake manifold.

Tightening torque:

6.4 N·m (0.65 kgf·m, 4.7 ft·lb)




- 3) Connect the fuel injector pipe RH to fuel hose, and tighten the clamp screw.



Intake Manifold


FUEL INJECTION (FUEL SYSTEMS)

4) Connect the fuel injector pipe LH to fuel hose, and tighten the clamp screw.




• LH side


Tightening torque:
19 N·m (1.9 kgf-m, 13.7 ft-lb)



5) Install the fuel injectors.
6) Install the clip which secures fuel injector.




Tightening torque:
6.4 N·m (0.65 kgf-m, 4.7 ft-lb)



7) Tighten the bolts which install injector pipe on intake manifold.


• RH side

Tightening torque:
19 N·m (1.9 kgf-m, 13.7 ft-lb)



8) Install the engine harness onto intake manifold.

Tightening torque:
6.4 N·m (0.65 kgf-m, 4.7 ft-lb)



Intake Manifold



FUEL INJECTION (FUEL SYSTEMS)

9) Secure the engine harness with harness band (A) and bolts (B), (C).

Tightening torque:


(B): 16 N·m (1.6 kgf-m, 11.8 ft-lb)

(C): 6.4 N·m (0.65 kgf-m, 4.7 ft-lb)



10) Install the purge control solenoid valve. <Ref. to EC(H4SO 2.0)-7, INSTALLATION, Purge Control Solenoid Valve.>


11) Connect the connectors to fuel injector.



12) Install the fuel pipe protector RH.

Tightening torque:


19 N·m (1.9 kgf-m, 13.7 ft-lb)




13) Install the fuel pipe protector LH.

Tightening torque:

19 N·m (1.9 kgf-m, 13.7 ft-lb)



14) Connect the pressure regulator vacuum hose to intake manifold.



15) Install the EGR valve. (EC, EK, K4 model) <Ref. to FU(H4SO 2.0)-28, INSTALLATION, EGR Valve.>


16) Install the throttle body to intake manifold. <Ref. to FU(H4SO 2.0)-10, INSTALLATION, Throttle Body.>

17) Install the ignition coil & ignitor ASSY. <Ref. to IG(H4SO 2.0)-8, INSTALLATION, Ignition Coil & Ignitor ASSY.>

18) Install the engine ground terminal to intake manifold.

Tightening torque:

19 N·m (1.9 kgf-m, 13.7 ft-lb)



E: INSPECTION

Make sure the fuel pipe and fuel hoses are not damaged and the connections are tightened firmly.


Engine Coolant Temperature Sensor

FUEL INJECTION (FUEL SYSTEMS)

4. Engine Coolant Temperature Sensor


A: REMOVAL

1) Disconnect the ground cable from battery.



2) Remove the generator. <Ref. to SC(H4SO 2.0)-14, REMOVAL, Generator.>

3) Disconnect the connectors from engine coolant temperature sensor.



4) Remove the engine coolant temperature sensor.

B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

18 N·m (1.8 kgf·m, 13.0 ft·lb)


Crankshaft Position Sensor

FUEL INJECTION (FUEL SYSTEMS)


5. Crankshaft Position Sensor

A: REMOVAL


1) Disconnect the ground cable from battery.



2) Remove the bolt which installs crankshaft position sensor to cylinder block.



3) Remove the crankshaft position sensor, and disconnect the connector from it.




B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

T: 6.4 N·m (0.65 kgf-m, 4.7 ft-lb)




Camshaft Position Sensor

FUEL INJECTION (FUEL SYSTEMS)


6. Camshaft Position Sensor

A: REMOVAL


1) Disconnect the ground cable from battery.




2) Disconnect the connector from camshaft position sensor.



3) Remove the bolt which installs camshaft position sensor to the support.




4) Remove the bolt which installs camshaft position sensor support to camshaft cap LH.



5) Remove the camshaft position sensor and the support as a unit.

6) Remove the camshaft position sensor itself.



B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

Camshaft position sensor support

6.4 N·m (0.65 kgf-m, 4.7 ft-lb)


Camshaft position sensor

6.4 N·m (0.65 kgf-m, 4.7 ft-lb)


7. Knock Sensor

A: REMOVAL


- 1) Disconnect the ground cable from battery.




- 2) Remove the air cleaner case. <Ref. to IN(H4SO 2.0)-6, REMOVAL, Air Cleaner Case.>
- 3) Remove the harness bracket from intake manifold.



- 4) Disconnect the knock sensor connector.



- 5) Remove the knock sensor from cylinder block.



B: INSTALLATION


- 1) Install the knock sensor to cylinder block.

NOTE:

Extraction area of knock sensor cord must be positioned at a 60° angle relative to the engine rear.


Tightening torque:

24 N·m (2.4 kgf-m, 17.4 ft-lb)



(A) Front side


- 2) Connect the knock sensor connector.



- 3) Install the harness bracket to intake manifold.

Tightening torque:

6.4 N·m (0.65 kgf-m, 4.7 ft-lb)




- 4) Install the air cleaner case.

<Ref. to IN(H4SO 2.0)-7, INSTALLATION, Air Cleaner Case.>

Knock Sensor

FUEL INJECTION (FUEL SYSTEMS)

5) Connect the battery ground cable to battery.



8. Throttle Position Sensor

A: SPECIFICATION

Throttle body is a non-disassembled part, so do not remove the throttle position sensor from throttle body.

Refer to “Throttle Body” for removal and installation procedure. <Ref. to FU(H4SO 2.0)-10, REMOVAL, Throttle Body.> <Ref. to FU(H4SO 2.0)-10, INSTALLATION, Throttle Body.>


Manifold Absolute Pressure Sensor

FUEL INJECTION (FUEL SYSTEMS)


9. Manifold Absolute Pressure Sensor

A: REMOVAL

1) Disconnect the ground cable from battery.



2) Disconnect the connector from manifold absolute pressure sensor.



3) Remove the manifold absolute pressure sensor from throttle body.

B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Use new O-rings.


Tightening torque:

2.0 N·m (0.20 kgf·m, 1.5 ft·lb)


10. Intake Air Temperature Sensor

A: REMOVAL

- 1) Disconnect the ground cable from battery.



- 2) Disconnect the connector from intake air temperature sensor.
- 3) Remove the intake air temperature sensor.



B: INSTALLATION

Install in the reverse order of removal.


11.EGR Valve

A: REMOVAL

NOTE:


EGR valve is equipped to EC, EK and K4 model.

1) Disconnect the ground cable from battery.



2) Disconnect the connector from EGR valve.

3) Remove the EGR valve from intake manifold.



B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Use a new gasket.

Tightening torque:


19 N·m (1.9 kgf·m, 13.7 ft·lb)

12. Fuel Injector


A: REMOVAL

1. RH SIDE


- 1) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 2) Open the fuel filler flap lid, and remove the fuel filler cap.
- 3) Disconnect the ground cable from battery.




- 4) Remove the air cleaner case. <Ref. to IN(H4SO 2.0)-6, REMOVAL, Air Cleaner Case.>
- 5) Remove the spark plug cords from spark plugs (#1 and #3 cylinders).
- 6) Remove the fuel pipe protector RH.





- 7) Disconnect the connector from fuel injector.



- 8) Remove the clip which secure fuel injector.



- 9) Remove the bolts which hold fuel injector pipe onto intake manifold.



- 10) Remove the fuel injector while lifting up the fuel injector pipe.


2. LH SIDE

- 1) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 2) Open the fuel filler flap lid, and remove the fuel filler cap.
- 3) Remove the battery.
- 4) Remove the spark plug cords from spark plugs (#2 and #4 cylinders).


Fuel Injector

FUEL INJECTION (FUEL SYSTEMS)


5) Remove the fuel pipe protector LH.





6) Disconnect the connector from fuel injector.



7) Remove the clips which secure fuel injector.



8) Remove the bolts which hold fuel injector pipe onto intake manifold.



9) Remove the fuel injector while lifting up the fuel injector pipe.

B: INSTALLATION

1. RH SIDE


Install in the reverse order of removal.

NOTE:

Use new O-rings.


Tightening torque:

19 N·m (1.9 kgf-m, 13.7 ft-lb)




Fuel Injector


Tightening torque:
6.4 N·m (0.65 kgf-m, 4.7 ft-lb)




Tightening torque:
19 N·m (1.9 kgf-m, 13.7 ft-lb)



Tightening torque:
19 N·m (1.9 kgf-m, 13.7 ft-lb)



Tightening torque:
19 N·m (1.9 kgf-m, 13.7 ft-lb)




2. LH SIDE

Install in the reverse order of removal.

NOTE:
Use new O-rings.

Tightening torque:
6.4 N·m (0.65 kgf-m, 4.7 ft-lb)




Front Oxygen (A/F) Sensor

FUEL INJECTION (FUEL SYSTEMS)


13. Front Oxygen (A/F) Sensor

A: REMOVAL

- 1) Disconnect the ground cable from battery.




- 2) Remove the air intake duct. <Ref. to IN(H4SO 2.0)-9, REMOVAL, Air Intake Duct.>
- 3) Remove the connector of front oxygen (A/F) sensor.



- 4) Remove the clip holding harness.
- 5) Lift-up the vehicle.
- 6) Remove the under cover.
- 7) Apply spray-type lubricant to the threaded portion of front oxygen (A/F) sensor, and leave it for one minute or more.
- 8) Remove the front oxygen (A/F) sensor.

CAUTION:

When removing the front oxygen (A/F) sensor, wait until exhaust pipe cools, otherwise it will damage the exhaust pipe.



B: INSTALLATION

- 1) Before installing front oxygen (A/F) sensor, apply anti-seize compound only to the threaded portion of front oxygen (A/F) sensor to make the next removal easier.

Anti-seize compound:
SS-30 JET LUBE


CAUTION:

Never apply anti-seize compound to the protector of front oxygen (A/F) sensor.


- 2) Install the front oxygen (A/F) sensor.

Tightening torque:


21 N·m (2.1 kgf·m, 15.2 ft·lb)



- 3) Install the under cover.
- 4) Lower the vehicle.
- 5) Hold the harness with clip.
- 6) Connect the connector of front oxygen (A/F) sensor.




- 7) Install the air intake duct. <Ref. to IN(H4SO 2.0)-9, INSTALLATION, Air Intake Duct.>
- 8) Connect the battery ground cable to battery.




14. Rear Oxygen Sensor

A: REMOVAL

- 1) Disconnect the ground cable from battery.




- 2) Lift-up the vehicle.
- 3) Disconnect the connector from rear oxygen sensor.



- 4) Remove the clip holding harness.
- 5) Apply spray-type lubricant to the threaded portion of rear oxygen sensor, and leave it for one minute or more.
- 6) Remove the rear oxygen sensor.

CAUTION:

When removing the rear oxygen sensor, wait until exhaust pipe cools, otherwise it will damage the exhaust pipe.



B: INSTALLATION

- 1) Before installing rear oxygen sensor, apply anti-seize compound only to the threaded portion of rear oxygen sensor to make the next removal easier.


Anti-seize compound:
SS-30 JET LUBE

CAUTION:


Never apply anti-seize compound to the protector of rear oxygen sensor.

- 2) Install the rear oxygen sensor.


Tightening torque:
21 N·m (2.1 kgf-m, 15.2 ft-lb)



- 3) Hold the harness with clip.
- 4) Connect the connector to rear oxygen sensor.



- 5) Lower the vehicle.
- 6) Connect the battery ground cable to battery.




Engine Control Module (ECM)

FUEL INJECTION (FUEL SYSTEMS)

15.Engine Control Module (ECM)

A: REMOVAL


1) Disconnect the ground cable from battery.



2) Remove the lower inner trim of passenger's side. <Ref. to EI-60, REMOVAL, Lower Inner Trim.>


3) Detach the floor mat of front passenger seat.

4) Remove the protect cover.



5) Remove the nuts (A) which hold ECM to bracket.

6) Remove the clip (B) from bracket.



7) Disconnect the ECM connectors and take out the ECM.

B: INSTALLATION

Install in the reverse order of removal.

CAUTION:

- When replacing the ECM, be careful not to use the wrong spec. ECM to avoid any damage to fuel injection system.
- When replacing the ECM, be careful not to damage the harnesses and connectors.


Tightening torque:

5 N·m (0.5 kgf-m, 3.6 ft-lb)

16.Main Relay


A: REMOVAL

1) Disconnect the ground cable from battery.




2) Remove the glove box. <Ref. to EI-51, REMOVAL, Glove Box.>

3) Remove the harness cover (A).



4) Disconnect the connector from main relay.



B: INSTALLATION

Install in the reverse order of removal.


Fuel Pump Relay

FUEL INJECTION (FUEL SYSTEMS)

17. Fuel Pump Relay


A: REMOVAL

1) Disconnect the ground cable from battery.




2) Remove the glove box. <Ref. to EI-51, REMOVAL, Glove Box.>

3) Remove the harness cover (A).



4) Disconnect the connector from fuel pump relay.




B: INSTALLATION

Install in the reverse order of removal.

18. Electronic Throttle Control Relay


A: REMOVAL

1) Disconnect the ground cable from battery.




2) Remove the glove box. <Ref. to EI-51, REMOVAL, Glove Box.>

3) Remove the harness cover (A).



4) Disconnect the connector from electric control throttle relay.



B: INSTALLATION

Install in the reverse order of removal.

19. Fuel


A: PROCEDURE

1. RELEASING OF FUEL PRESSURE

WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

1) Remove the fuse of fuel pump from main fuse box.




- 2) Start the engine and run until it stalls.
- 3) After the engine stalls, crank it for five more seconds.
- 4) Turn the ignition switch to OFF.

2. DRAINING FUEL

WARNING:


- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.



- 3) Open the fuel filler flap lid, and remove the fuel filler cap.
- 4) Lift-up the vehicle.
- 5) Remove the fuel tank protector.

6) Set a container under the vehicle and remove the drain plug from fuel tank to drain fuel from the fuel tank.



7) Tighten the fuel drain plug.

NOTE:

Use a new gasket.

Tightening torque:

26 N·m (2.65 kgf-m, 19.2 ft-lb)

8) Install the fuel tank protector.

NOTE:

Use a new nut.

Tightening torque:

Nut

9.0 N·m (0.92 kgf-m, 6.6 ft-lb)

Bolt

17.5 N·m (1.78 kgf-m, 12.9 ft-lb)


20. Fuel Tank

A: REMOVAL


WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

- 1) Set the vehicle on a lift.
- 2) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 3) Drain fuel from the fuel tank.
<Ref. to FU(H4SO 2.0)-38, DRAINING FUEL, PROCEDURE, Fuel.>
- 4) Remove the rear seat.
- 5) Remove the service hole cover from fuel pump.
 - (1) Remove the bolts (A).
 - (2) Push the grommet (B) down under the body and remove the service hole cover.




- 6) Disconnect the connector from fuel pump.




- 7) Remove the service hole cover from fuel sub level sensor.
 - (1) Remove the bolts (A).


- (2) Push the grommet (B) down under the body and remove the service hole cover.



- 8) Disconnect the connector (A) from fuel sub level sensor.
- 9) Disconnect the quick connector from the fuel delivery (B) and return hose (C). <Ref. to FU(H4SO 2.0)-53, REMOVAL, Fuel Delivery, Return and Evaporation Lines.>




- 10) Remove the rear wheels.
- 11) Remove the bolts which secure rear brake hose installation bracket.



Fuel Tank

FUEL INJECTION (FUEL SYSTEMS)

12) Remove the rear brake caliper and tie it to the side of vehicle body.



13) Remove the parking brake cable from parking brake assembly. <Ref. to PB-7, REMOVAL, Parking Brake Assembly (Rear Disc Brake).>

14) Lift-up the vehicle.


15) Remove the rear exhaust pipe.

<Ref. to EX(H4SO 2.0)-11, REMOVAL, Rear Exhaust Pipe.>



16) Remove the propeller shaft. <Ref. to DS-10, REMOVAL, Propeller Shaft.>

17) Remove the heat shield cover.

18) Disconnect the connector from rear ABS wheel speed sensor.



19) Remove the bolts which install parking brake cable clamp.




20) Remove the rear suspension assembly.

CAUTION:

A helper is required to perform this work.



- (1) Support the rear differential with transmission jack.
- (2) Remove the bolt which installs rear shock absorber to rear suspension arm.




Fuel Tank

FUEL INJECTION (FUEL SYSTEMS)


(3) Remove the bolts which secure rear suspension assembly to body.



(4) Remove the rear suspension assembly.
21) Disconnect the two-way valve hose (A) from two-way valve, and then remove the two-way valve from bracket.




22) Loosen the clamp and disconnect the fuel filler hose (A) and vent hose (B) from fuel filler pipe.



23) Support the fuel tank with transmission jack, remove the bolts from fuel tank bands and dismount the fuel tank from vehicle.


WARNING:
A helper is required to perform this work.



B: INSTALLATION

1) Support the fuel tank with transmission jack, set the fuel tank, and then temporarily tighten the bolts of fuel tank band.



WARNING:
A helper is required to perform this work.



Fuel Tank


FUEL INJECTION (FUEL SYSTEMS)

2) Correctly insert the fuel filler hose (A) and vent hose (B) to specified position, and then tighten the clamp.



- (1) Hose
- (2) Clip or clamp
- (3) Pipe

3) Install the two-way valve to bracket, and connect the two-way valve hose (A) to two-way valve.



4) Tighten the bolts of fuel tank band.

Tightening torque:

33 N·m (3.4 kgf-m, 25 ft-lb)

5) Install the rear suspension assembly.

CAUTION:

A helper is required to perform this work.



- (1) Support the rear differential with transmission jack.
- (2) Support the rear suspension assembly, and then tighten the bolts which secure rear suspension assembly to body.

Tightening torque:

T1: 125 N·m (12.7 kgf-m, 92.2 ft-lb)

T2: 65 N·m (6.2 kgf-m, 48 ft-lb)


T3: 175 N·m (17.8 kgf-m, 129 ft-lb)



(3) Tighten the bolts which install rear shock absorber to rear suspension arm. <Ref. to RS-11, INSTALLATION, Rear Arm.>

Tightening torque:

62 N·m (6.3 kgf-m, 46 ft-lb)




6) Tighten the bolts which install parking brake cable clamp.

Fuel Tank

FUEL INJECTION (FUEL SYSTEMS)


Tightening torque:

18 N·m (1.8 kgf-m, 13.0 ft-lb)




Tightening torque:

32 N·m (3.3 kgf-m, 23.9 ft-lb)




7) Connect the connector to ABS wheel speed sensor.



- 8) Install the heat shield cover.
- 9) Install the propeller shaft. <Ref. to DS-11, INSTALLATION, Propeller Shaft.>
- 10) Install the rear exhaust pipe. <Ref. to EX(H4SO 2.0)-11, INSTALLATION, Rear Exhaust Pipe.>
- 11) Lower the vehicle.
- 12) Connect the parking brake cable to parking brake assembly. <Ref. to PB-8, INSTALLATION, Parking Brake Assembly (Rear Disc Brake).>
- 13) Install the rear brake caliper.
- 14) Tighten the bolt which secures rear brake hose installation bracket.

Tightening torque:


33 N·m (3.4 kgf-m, 25 ft-lb)




- 15) Install the rear wheels.
- 16) Lower the vehicle.
- 17) Connect the connector (A) to fuel sub level sensor.
- 18) Connect the quick connector to the fuel delivery (B) and return hose (C). <Ref. to FU(H4SO 2.0)-54, INSTALLATION, Fuel Delivery, Return and Evaporation Lines.>

NOTE:

Be careful not to misconnect the delivery side and return side.



19) Install the service hole cover of fuel sub level sensor.




- (A) Bolt
- (B) Grommet


Fuel Tank

FUEL INJECTION (FUEL SYSTEMS)

20) Connect the connector to fuel pump.



21) Install the service hole cover of fuel pump.



(A) Bolt

(B) Grommet

22) Install the rear seat.

23) Install the fuse of fuel pump to main fuse box.

C: INSPECTION

1) Check that the fuel tank is not holed, cracked, or otherwise damaged.

2) Make sure that the fuel hoses and fuel pipes are not cracked and those connections are tight.


21. Fuel Filler Pipe

A: REMOVAL


WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.


- 1) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 2) Open the fuel filler flap lid, and remove the filler cap.
- 3) Disconnect the ground cable from battery.




- 4) Remove the screws which secure the packing.



- 5) Lift-up the vehicle.
- 6) Remove the rear wheel RH.



- 7) Set a container under the vehicle and remove the drain plug from fuel tank to drain fuel from the fuel tank.



- 8) Tighten the fuel drain plug.


NOTE:

Use a new gasket.


Tightening torque:

26 N·m (2.65 kgf-m, 19.2 ft-lb)

- 9) Remove the mud guard. <Ref. to EI-29, REMOVAL, Mud Guard.>
- 10) Remove the rear sub frame. <Ref. to RS-23, REMOVAL, Rear Sub Frame.>
- 11) Remove the bolts which hold fuel filler pipe bracket on the body.



- 12) Loosen the clamp and disconnect the fuel filler hose (A) and vent hose (B) from fuel filler pipe.



- 13) Remove the fuel filler pipe to under side of the vehicle.

Fuel Filler Pipe


FUEL INJECTION (FUEL SYSTEMS)

B: INSTALLATION



- 1) Open the fuel filler flap lid.
- 2) Set the fuel saucer (A) with rubber packing (C) and insert the fuel filler pipe into hole from the inner side of apron.
- 3) Align the holes in fuel filler pipe neck and set the cup (B), and tighten the screws.

NOTE:

If the edges of rubber packing are folded toward the inside, straighten it with a flat tip screwdriver.



- 4) Correctly insert the fuel filler hose (A) and vent hose (B) to specified position, and then tighten the clamp.




- (1) Hose
- (2) Clip or clamp
- (3) Pipe


- 5) Tighten the bolts which hold fuel filler pipe bracket on the body.

Tightening torque:


7.5 N·m (0.75 kgf-m, 5.4 ft-lb)



- 6) Install the rear sub frame. <Ref. to RS-23, INSTALLATION, Rear Sub Frame.>
- 7) Install the mud guard. <Ref. to EI-29, INSTALLATION, Mud Guard.>
- 8) Install the rear wheel RH.



- 9) Lower the vehicle.
- 10) Install the fuse of fuel pump to main fuse box.
- 11) Connect the battery ground cable to battery.



22. Fuel Pump

A: REMOVAL


WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.
- Reduce the fuel in the fuel tank to less than 3/4 beforehand. Be careful that fuel may spill when the fuel is more than 3/4.


NOTE:

Fuel pump assembly consists of fuel pump and fuel level sensor.

- 1) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 2) Drain fuel. <Ref. to FU(H4SO 2.0)-38, DRAINING FUEL, PROCEDURE, Fuel.>
- 3) Remove the rear seat.
- 4) Remove the service hole cover.
 - (1) Remove the bolts (A).
 - (2) Push the grommet (B) down under the body and remove the service hole cover.




- 5) Disconnect the connector from fuel pump.



- 6) Disconnect the quick connector and then disconnect the fuel delivery hose, return hose and jet pump hose. <Ref. to FU(H4SO 2.0)-53, REMOVAL, Fuel Delivery, Return and Evaporation Lines.>

- 7) Remove the nuts which install fuel pump assembly onto fuel tank.



- (A) Delivery hose
- (B) Return hose
- (C) Jet pump hose

- 8) Take off the fuel pump assembly from fuel tank.

B: INSTALLATION

Install in the reverse order of removal.


NOTE:

Use a new gasket.

- (1) Ensure the sealing portion is free from fuel or foreign particles before installation.
- (2) Tighten the nuts to specified torque in the order as shown in the figure.

Tightening torque:

4.4 N·m (0.45 kgf·m, 3.3 ft·lb)



C: INSPECTION

Connect the lead harness to the connector terminal of fuel pump and apply the battery power supply to check whether the pump operates.


WARNING:

- Wipe off the fuel completely.
- Keep battery as far apart from fuel pump as possible.
- Be sure to turn the battery supply to ON and OFF on the battery side.

Fuel Pump

FUEL INJECTION (FUEL SYSTEMS)

- Do not run fuel pump for a long time under non-load condition.



23. Fuel Level Sensor

A: REMOVAL


WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

NOTE:

Fuel level sensor is built in fuel pump assembly.

- 1) Remove the fuel pump assembly. <Ref. to FU(H4SO 2.0)-47, REMOVAL, Fuel Pump.>
- 2) Disconnect the connector from fuel pump bracket.



- 3) Remove the fuel level sensor.

B: INSTALLATION

Install in the reverse order of removal.

Fuel Sub Level Sensor

FUEL INJECTION (FUEL SYSTEMS)


24. Fuel Sub Level Sensor

A: REMOVAL


WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.
- Reduce the fuel in the fuel tank to less than 3/4 beforehand. Be careful that fuel may spill when the fuel is more than 3/4.

- 1) Drain fuel. <Ref. to FU(H4SO 2.0)-38, DRAINING FUEL, PROCEDURE, Fuel.>
- 2) Remove the rear seat.
- 3) Remove the service hole cover.
 - (1) Remove the bolts (A).
 - (2) Push the grommet (B) down under the body and remove the service hole cover.




- 4) Disconnect the connector from fuel sub level sensor.



- 5) Disconnect the quick connector and then disconnect the fuel delivery hose, return hose and jet pump hose. <Ref. to FU(H4SO 2.0)-53, REMOVAL, Fuel Delivery, Return and Evaporation Lines.>

- 6) Remove the bolts which install the fuel sub level sensor on fuel tank.



- (A) Jet pump hose
- (B) Delivery hose
- (C) Return hose

- 7) Remove the fuel sub level sensor.

B: INSTALLATION

Install in the reverse order of removal.



NOTE:

Use a new gasket.

- (1) Ensure the sealing portion is free from fuel or foreign particles before installation.
- (2) Tighten the nuts and bolts to specified torque in the order as shown in the figure.

Tightening torque:

4.4 N·m (0.45 kgf·m, 3.3 ft·lb)



25. Fuel Filter

A: SPECIFICATION

Fuel filter forms a unit with fuel pump.

Refer to Fuel Pump for removal and installation.

<Ref. to FU(H4SO 2.0)-47, REMOVAL, Fuel Pump.>


<Ref. to FU(H4SO 2.0)-47, INSTALLATION, Fuel Pump.>

26. Fuel Damper Valve

A: REMOVAL

1. DELIVERY SIDE

- 1) Release the fuel pressure.
<Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 2) Remove the fuel damper valve from fuel delivery line.



2. RETURN SIDE

Fuel damper valve forms a unit with fuel injector pipe RH.

Refer to "Intake Manifold" for removal. <Ref. to FU(H4SO 2.0)-14, DISASSEMBLY, Intake Manifold.>

B: INSTALLATION

1. DELIVERY SIDE

Install in the reverse order of removal.

Tightening torque:

1.25 N·m (0.13 kgf-m, 0.94 ft-lb)

2. RETURN SIDE


Fuel damper valve forms a unit with fuel injector pipe RH.

Refer to "Intake Manifold" for installation. <Ref. to FU(H4SO 2.0)-16, ASSEMBLY, Intake Manifold.>

27. Fuel Delivery, Return and Evaporation Lines


A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Release the fuel pressure. <Ref. to FU(H4SO 2.0)-38, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>
- 3) Open the fuel filler flap lid, and remove the fuel filler cap.
- 4) Remove the floor mat. <Ref. to EI-73, REMOVAL, Floor Mat.>
- 5) Disconnect the fuel delivery pipes and hoses, and then disconnect the fuel return pipes and hoses, evaporation pipes and hoses.



FU-01148

- 6) In the engine compartment, disconnect the fuel delivery hoses, return hoses and evaporation hose.




FU-02062

- (A) Fuel delivery hose
- (B) Return hose
- (C) Evaporation hose

- 7) Lift-up the vehicle.
- 8) Remove the fuel tank. <Ref. to FU(H4SO 2.0)-39, REMOVAL, Fuel Tank.>

- 9) Separate the quick connector on fuel line.
 - (1) Clean the pipe and connector, if they are covered with dust.
 - (2) To prevent from damaging or entering foreign matter, wrap the pipes and connectors with plastic bag, etc.



FU-01333


- (3) Hold the connector (A) and push retainer (B) down.
- (4) Pull out the connector (A) from retainer (B).

Fuel Delivery, Return and Evaporation Lines

FUEL INJECTION (FUEL SYSTEMS)

CAUTION:

Always use a new retainer.




- (A) Connector
- (B) Retainer
- (C) Pipe

B: INSTALLATION

1) Connect the quick connector on fuel line.


CAUTION:

- Always use a new retainer.
- Make sure that the connected portion is not damaged or has dust. If necessary, clean the seal surface of pipe.



- (A) Seal surface
- (B) Pipe


- (1) Set the new retainer (B) to connector (A).
- (2) Push the pipe into the connector completely.



- (A) Connector
- (B) Retainer
- (C) Pipe

CAUTION:

- Pull the connector to ensure it is connected securely.
- Ensure the two retainer pawls are engaged in their mating positions in the connector.
- Be sure to inspect the hoses and their connections for fuel leakage.




- (A) Connector
- (B) Retainer
- (C) Pipe

2) Connect the fuel delivery hose to the pipe with an overlap of 20 to 25 mm (0.79 to 0.98 in).

Type A: When the amount of inserting is specified.
Type B: When the amount of inserting is not specified.

$\varnothing : 2.5 \pm 1.5 \text{ mm } (0.098 \pm 0.059 \text{ in})$

$L : 22.5 \pm 2.5 \text{ mm } (0.886 \pm 0.098 \text{ in})$



- (1) Pipe
- (2) Clamp
- (3) Hose

3) Connect the return hose and evaporation hose to pipe by approx. 15 mm (0.59 in) from the hose end.

Fuel return hose:


$L = 22.5 \pm 2.5 \text{ mm } (0.885 \pm 0.098 \text{ in})$

Fuel evaporation hose:

$L = 17.5 \pm 2.5 \text{ mm } (0.689 \pm 0.098 \text{ in})$

CAUTION:

Be sure to inspect the hoses and their connections for fuel leakage.



- (1) Hose
- (2) Clip
- (3) Pipe

C: INSPECTION

- 1) Make sure that there are no cracks on the fuel pipes and fuel hoses.
- 2) Make sure that the fuel pipe and fuel hose connections are tightened firmly.

Fuel System Trouble in General

FUEL INJECTION (FUEL SYSTEMS)

28. Fuel System Trouble in General

A: INSPECTION

Trouble and possible cause		Corrective action
1. Insufficient fuel supply to injector		
1)	Fuel pump does not operate.	
	○ Defective terminal contact.	Inspect contact, especially ground, and tighten it securely.
	○ Trouble in electromagnetic or electronic circuit parts.	Replace the faulty parts.
2)	Decline of fuel pump function.	Replace the fuel pump.
3)	Clogged dust or water in the fuel filter.	Replace fuel filter, clean or replace fuel tank.
4)	Clogged or bent fuel pipe or hose.	Clean, correct or replace the fuel pipe or hose.
5)	Air is mixed in the fuel system.	Inspect or retighten each connection part.
6)	Clogged or bent air breather tube or pipe.	Clean, correct or replace air breather tube or pipe.
7)	Damaged diaphragm of pressure regulator.	Replace.
2. Leakage or blow out of fuel		
1)	Loosened joints of the fuel pipe.	Retightening.
2)	Cracked fuel pipe, hose and fuel tank.	Replace.
3)	Defective welding part on the fuel tank.	Replace.
4)	Defective drain packing of the fuel tank.	Replace.
5)	Clogged or bent air breather tube or air vent tube.	Clean, correct or replace air breather tube or air vent tube.
3. Gasoline smell inside of compartment		
1)	Loose joints at air breather tube, air vent tube and fuel filler pipe.	Retightening.
2)	Defective packing air tightness on the fuel saucer.	Correct or replace the packing.
3)	Inoperative fuel pump modulator or circuit.	Replace.
4. Defective fuel meter indicator		
1)	Defective operation of fuel level sensor.	Replace.
2)	Defective operation of fuel meter.	Replace.
5. Noise		
1)	Large operation noise or vibration of fuel pump.	Replace.

NOTE:

- When the vehicle is left unattended for an extended period of time, water may accumulate in the fuel tank. Fill fuel fully to prevent those problem. And also drain the water condensation from fuel filter.
- In snow-covered areas, mountainous areas, skiing areas, etc. where ambient temperatures drop below 0°C (32°F) throughout the winter season, use water removing agent in the fuel system to prevent freezing fuel system and accumulating water. Fill the water removing agent at the time when the fuel reduced at half to maintain the advantage.
- When water condensation is noticed in the fuel filter, drain the water from both the fuel filter and fuel tank or use water removing agent in the fuel tank.
- Before using water removing agent, follow the cautions noted on the bottle.